

Attachment 6

Information Required for "Subsequent Report of Abandonment" Sundry

1. Use form 3160-5 "Sundry Notices and Reports on Wells" (see Attachment 9 - Example "Subsequent Report of Abandonment").
2. Check the boxes - "Subsequent Report" and "Abandonment".
3. Submit a final closure report to the BLM and Regional Water Quality Control Board. At the same time, the Division of Oil and Gas will be provided the information contained in (d) below. At a minimum, the report will include the following four items:
 - a. Photographs of "Pre-work", "Post-excavation" and "Post-work" conditions. Date and label all photographs.
 - b. Results of work performed in steps 1, 5-8, and 11.
 - c. Documentation of impoundment location (restate location description from Attachment 2, step 2), size, and description of operations. Include the depth and estimated volume of the excavated material.
 - d. State whether any visibly stained soil was left in place. If any visibly stained soil was left in place overlying an aquifer that is not EPA exempt, indicate the distance between the bottom of the excavation and that aquifer. Provide a rationale on how the groundwater is protected from the effects of remaining materials.
 - e. The Operator must state in the "Subsequent Report of Abandonment,": "The Operator understands, agrees, and acknowledges BLM DOES NOT WAIVE THE RIGHT to require the Operator to further investigate and/or address any environmental condition at the site caused by the sump in accordance with applicable laws and regulations."

All of the items in steps 1-3 must be provided in order for the Subsequent Report of Abandonment to be approved.